

Armor-Tile

Tactile Systems

Replaceable Herculite

Installation Instructions

NOTE: Tiles can be cut to custom sizes, or to make a radius, using a continuous rim diamond blade in a circular saw or mini-grinder. Use of a straightedge to guide the cut is advisable where appropriate.

Recommended Tools and Materials:

- White, or non-marking rubber mallet
- Sand bags
- 3/8" radius edging tool
- Steel trowel
- Sharp exacto knife
- Hard plastic bristle brush
- Continuous rim diamond blade in a circular saw or mini-grinder.

Installation Instructions:

1. Maintaining a 4-7 slump range, pour and float the concrete.
2. Without removing any concrete, place the tile 6-8" from the curb line (face of curb).

IMPORTANT: Recess the tile installation by 3mm (+/-1mm) (Compliant to CSA B651-18) to reduce potential damage by snow clearing vehicles.

3. Tamp the tile in grid pattern across the top face, embedding the tile into the concrete using a white or (non-marking) rubber mallet or vibrate into place using a vibrating mechanism fixed with a soft base such as wood, at least 1 foot square.
4. Place sandbags or 25lb weights on the tile to prevent floating.
5. Create an edge around the perimeter of the tile using a 3/8" radius edging tool then float the concrete around the tile's perimeter using a steel trowel.

NOTE: Using the 3/8" radius edging tool create a a weep channel from tile to curb to allow water to drain from the surface of the tile.

7. After the concrete has substantially cured, remove the protective plastic wrap by cutting the plastic with a sharp knife tight to the concrete/tile interface.
8. If concrete bled under the plastic, a soft wire brush will clean the residue without damage to the tile surface.

Replacement Instructions

- A. Unscrew T27 tamper-proof fasteners.
- B. Tap perimeter of tile with a rubber mallet to remove bond of tile to concrete.
- C. Use a pry bar to pry up an edge. Remove all debris from vacant cavity mold. Vacuum/sweep all crevices.
- D. Insert replacement tile, gently apply pressure to seat tile in recess. Reinsert tamper-proof fasteners in hex shape concrete anchors.

For more information about Armror Tile Replaceable Herculite Tactile Walking Surface Indicators scan the QR code below:

