



INSTALLATION

Manubric offers products easy to install in a few simple steps.

1. Apply the adhesive with a trowel on your wall. We recommend starting from the bottom to the top and only cover small surfaces at the time with the adhesive to prevent drying.
2. Start installing bricks until the row is complete and then verify with a level before starting the second row.
3. Start the second row with a half-brick then alternate the beginning of your next row with a full brick. Always alternate the first brick with a half-brick and then full brick.
4. Before filling the joints, wait 24 to 48 hours to let the adhesive to dry.
5. Fill the gaps / joints in-between the bricks on the wall using a cone applicator, making sure to completely fill the extremities.
- Please refer to the manufacturer instructions to prepare the grout mix for the proper procedures.
(May vary from one company to another)
6. We recommend wearing rubber gloves. Smooth out the surface of the joints using the tip of your finger, until you get an even spread.
7. Clean and polish; Use a soft hairbrush to remove any residue on the brick wall. Never wash the joints and bricks with water. Wipe dirt and stains using a soft and dry cloth.

Recommended product for the installation		
Adhesive	Manubric's adhesive	Covers at max 15 sq. ft. /L
Grout	Polyblend non-sanded grout	Covers at max 650 sq. ft./ 4.5L

We highly recommend watching our installation video before starting:
<https://www.youtube.com/watch?v=nARlumuSO4s>

Tools required for the installation.
Plaster knife
Level
Square
Trowel
Square
Measurement tape