

MOLDING INSTALLATION GUIDE

General installation instructions for T-Molding, Reducer and Square Nose moldings

All Beaulieu Canada moldings described below come with a trim track for an easy and sturdy installation. Follow these simple steps to install your moldings:

- 1. Cut the molding and trim track to the required length.
- 2. Screw or glue the trim track to the subfloor.
- 3. Allow a ¼" expansion gap between the trim track and the flooring.
- 4. Press the molding into the trim track until it is firmly in place. A rubber mallet may be required to fully engage it into the trim track.

