

TYPICAL APPLICATIONS

PROVA-MAT is ideally suited for waterproofing vertical and horizontal substrates where ceramic and stone tile will be installed such as in showers, bathrooms, wellness areas, steam rooms, saunas, and exterior patios, balconies and decks that are not covering occupied space.

ACCESSORIES



1. PREPARATION

Substrate must be clean, dry, flat and structurally sound. Bonding adhesive must be able to bond to substrate.



INSTALLATION: CORNERS

PROVA-CORNERS and PROVA-JOINT installed first. Work from bottom to top. Apply recommended mortar to substrate using a 1/4" x 3/16" V-notch trowel. **For most substrates, a premium modified thin set mortar is recommended. Work PROVA-CORNERS and PROVA-JOINT into wet mortar using a flat trowel or float, taking care not to cut material or create air pockets.



INSTALLATION: PROVA-MAT

Work from bottom to top. Start with floor, then walls, last ceiling. ** Apply recommended mortar to substrate using a 1/4" x 3/16" V-notch trowel.



INSTALLATION: JOINTS

Overlap joints by a minimum of 2". Sheets may be butted and covered with PROVA-JOINT.



INSTALLATION: TILING

Desired finished tile or stone may be installed immediately after PROVA-MAT installation or at a later date using ** recommended mortar and trowel size to create bond between tile or stone and substrate.



For further information CONTACT:
 1 800 565 6653 service@mdteam.com
 provaproducts.com