

PROVA CURB®

INSTALLATION SUMMARY



Step 1: CUT PROVA CURB® TO SIZE

Measure and cut PROVA CURB® as required. Place the cut edges against the wall.



Step 2: TROWEL PROVA CURB® WITH MODIFIED THINSET

Apply modified thinset to the substrate area next to the PROVA PAN® using a 1/4" x 3/18" up to a 1/2" x 1/2" square-notch trowel.



Step 3: APPLY MODIFIED THINSET TO PROVA CURB®

Fill the dovetail recess under the PROVA CURB® with modified thinset and press the curb into place.



Step 4: WATERPROOF WITH PROVA-MAT®

Apply modified thinset to the outside surfaces of the PROVA CURB® using a 1/4" x 3/16" V-notch trowel. Cover the surfaces with PROVA-MAT®, ensuring that it overlaps the PROVA PAN® by 2".



THINSET CURING TIME

Do not move the PROVA CURB® for at least 24 hours, allowing the modified thinset to cure.