

Osmo Floor Brushes Application Instructions

- 1. Stir the Osmo Polyx-Oil finish well and pour into a tray.
- 2. Take the Osmo Floor Brush and dip approximately 1cm into product.
- 3. Brush the Osmo Polyx-Oil very thinly and evenly onto the wood floor following the grain in a back-and-forth scrubbing motion.
- 4. Take care to avoid brush-stops, excessive areas of product
- 5. Store the brush in a plastic bag overnight to prevent drying
- 6. Clean with Osmo Brush Cleaner and Thinner 8000