

Application Stain CG Plancher

1st step : The wood must be sanded with a paper 150 clean and dusted

2nd step: Make sure to stir the stain well before and during use, transfer your container to be sure you have stirred well so there is no left pigment in the bottom of the can.

Apply with a stain pad or sponge brush evenly and generously over the entire surface to be finished. Quickly wipe off excess with a Cloth.

To avoid overlap marks, apply the stain generously and evenly as quickly as possible. Wipe off any excess.

3rd step : Apply the white base evenly and let dry 45 min.

4th step: Apply the color evenly and let dry for 1 hour.

Apply a finish of your choice**Water-based stain**

