

SURFACE PREPARATION | SELF-LEVELING UNDERLAYMENTS

PRO FLOWLEVEL™ FIBER REINFORCED

2. MANUFACTURER

PROMA ADHESIVES Inc.

9801, Parkway, Anjou, Quebec Canada H1J 1P3 Tel.: 514.852.8585

Fax: 514.852.8225

Toll-free: 1 866.51.PROMA (77662)

Email: info@proma.ca Web: www.proma.ca

3. PRODUCT DESCRIPTION

PRO FLOWLEVEL™ FIBER REINFORCED is a very high-strength, high-performance, quicksetting, low-prep, single component, highly polymer-modified, fiber reinforced self-leveling and self-finishing underlayment. PRO FLOWLEVEL™ FIBER REINFORCED is formulated with PROMA's exclusive **Stabilized Technology™**, which minimizes movement and shrinkage during curing for superior results. The product also greatly reduces the need for shotblasting and profiling saving valuable time and money.

Features

- Pour from 3 mm (1/8") to 50 mm (2") thick in a single application
- Walking time: 4 to 6 hours after pour; light traffic: 24 to 48 hours after pour
- Creates a smooth, level and uniform surface
- Formulated with PROMA's exclusive Stabilized Technology™, which minimizes movement and shrinkage during curing for superior results
- Greatly reduces the need for shotblasting and profiling saving valuable time and money
- Fiber-reinforced formula for exceptional strength
- Can be used on critical substrates when used in conjunction with PROMA's fiberglass woven mesh PRO FLOWLEVEL FIBER MESH
- Install ceramic, porcelain or natural stones, resilient floor covering, carpet, laminate flooring, engineered wood and wood parquet after 48 hours (when poured at a thickness of 6 mm [1/4"] or less)*
- Mix only with water
- Oualifies as part of PROMA's LIMITED WARRANTY PROGRAM up to a LIFETIME (contact PROMA for details)
- For interior institutional, commercial and residential applications
- Compatible with most setting materials, adhesives and floor coverings including wood parquet and rubber, once dried and sealed
- Can be barrel mixed or pumped through most standard pumps Can be used for encapsulation over asbestos based tiles and some glue residues



Concrete

Exterior-Grade Plywood













- Can be used as a thermal mass over hydronic and electric radiant systems
- Superior compressive strength and flexural resistance
- Low Shrinkage
- Will not promote mold, mildew or bacteria growth
- Eco friendly for users of the material
 - * Refer to Drying Time table in Curing and Protection section for further details.

Packaging

40 lb (18 kg) plastic bag

PRO FLOWLEVEL" FIBER REINFORCED



Suitable Substrates

- Dry, completely cured concrete (at least 28 days old)
- Cement backer units (CBU)
- Sound Mats (see Limitations)
- Gypsum and light-weight concrete surfaces^{† *}
- Existing ceramic and quarry tiles, porcelain, granite and marble
- Cementitious and Epoxy Terrazzo floors[†]
- OSB/Exterior Grade Douglas Fir Plywood, certified CANPLY (SELECT) or (SEL-TF) CSA 121, for INTERIOR Residential Light-Duty Floors in dry areas only[†]
- Metal such as steel, copper, stainless steel, aluminum or lead[†]
- Old cut-back adhesive residue and water-soluble adhesive residues[†]
- Existing VAT and VCT tiles, and non-cushioned vinyl sheet goods[†]
- Homogeneous PVC flooring[†]
- Resin-based floor coverings (epoxy, urethane or polyurethane)[†]
 - † When primed with PRO SUPERPRIME™ or PRO SUPERPRIME™ 1C (see respective data sheet for details)
 - Provided that the tensile bond strength of 72 psi (0.5 MPa) is reached as a minimum for self-leveling applications

Limitations

- For INTERIOR installations only.
- Do not use at temperatures below 10°C (50°F) or above 35°C (95°F).
- Do not use for applications exceeding 50 mm (2") in thickness. For installations exceeding 50 mm (2") in thickness, contact our technical department for proper recommendations.
- Do not apply directly over particleboard, chipboard, presswood, Lauan, masonite and other dimensionally unstable materials.
- Do not apply below a thickness of 32 mm (1 1/4") over plywood or OSB substrates, unless used over double-layered plywood then minimum thickness is 6 mm (1/4") or unless used in conjunction with PROMA fiber mesh. Please contact our technical department for proper recommendations.
- Do not apply below a thickness of 38 mm (1 1/2") on sound mat. Please contact our technical department for proper recommendations.
- Allow PRO FLOWLEVEL™ FIBER REINFORCED to dry properly prior to installing the floor covering.
- Do not leave without floor covering or exposed as a resurfacing material.
- When using a self-leveling product over a radiant heating system (previously checked for good functioning), turn the system off 24 hours prior to the installation and wait at least 2 weeks before turning it back on.
- Existing ceramic tiles, composite vinyl tiles, terrazzo, metal, epoxy-resin floors or old cut-back adhesives must be well prepared and primed with PRO SUPERPRIME™ or PRO SUPERPRIME 1C prior to installing PRO FLOWLEVEL™ FIBER REINFORCED (see respective technical data sheet).
- Do not use for filling cracks, holes and deep areas. Use PRO CEMIX™ for those purposes (see respective technical data sheets for details).
- Do not use where high moisture and hydrostatic conditions and/or recurring moisture problems exist.
- Do not use in places subject to immersion.
- Do not add water to the mix once it begins to thicken.
- Do not add sand, aggregate or additional water to the mix.
- Protect from any direct air ventilation or heat radiation source, such as direct sunlight, during and after the installation, for a minimum of 48 hours. These conditions could cause the self-leveling product to cure too rapidly, resulting in micro- cracking.
- Do not accelerate curing time by using ventilators or heating appliances.

4. TECHNICAL DATA

NOTE: The technical data provided is averaged based on lab testing under controlled conditions (23° C [73° F] and 50% RH), done in accordance with standard industry testing methods (where applicable), and is subject to change without notice. Actual performance may vary depending on jobsite conditions and installation methods used. Please contact our technical services department for additional information.

PHYSICAL PROPERTIES (@23° C [73° F] and 50% RH)		
Working time	≥ 20 minutes	
Flow time	≥ 20 minutes	
Final set time	4 hours	
Time before installing floor covering	Reference 'Curing and Protection'	
Time before installing ceramic tile	Reference 'Curing and Protection'	

^{*}Please contact our Technical Service Department for further information

MECHANICAL PROPERTIES (@23° C [73° F] and 50% RH)		
VOC content	0 g/L	
Linear shrinkage (%) @ 28 days	< 0.02%	
Flexural strength (ASTM C-348) @ 28 days	> 8.3 MPa (1,200 psi)	
Tensile bond strength (ASTM D4541 [Concrete]) @ 7 days	> 2.8 MPa (400 psi)	
Compressive strength (ASTM C-109) @ 28 days	> 34.5 MPa (5,000 psi)	
Density	2.0 g/mL	
Shelf life		
12 months if kept in its original unopened packaging and stored in a dry location.		

Approximate coverage per 18 kg (40 lb) bag		
Thickness	Coverage	
3 mm (1/8")	3.7 m² (40 ft²)	
6 mm (1/4")	1.9 m² (20 ft²)	
12 mm (1/2")	0.9 m² (10 ft²)	
25 mm (1")	0.5 m² (5 ft²)	

5. INSTALLATION

Surface Preparation

(Refer to PROMA Surface Preparation Guidelines for complete details)

Note: Shot-blasting or profiling is not required for most concrete flooring when using PRO FLOWLEVEL FIBER REINFORCED. When in doubt, PRO SUPERPRIME™ OF PRO SUPERPRIME™ 1C can be used to ready nearly any surface for PROMA leveling underlayments without the need for scarifying or shotblasting, saving valuable time and money (see respective technical data sheet for details). When encountering any questionable or critical substrates with out-of-plane movement, PRO FLOWLEVEL FIBER REINFORCED can be used in conjunction with PROMA's fiberglass woven mesh PRO FLOWLEVEL FIBER MESH (contact our Technical Service Department for appropriate recommendations).

- All supporting surfaces must be structurally sound, solid and stable.
- Surfaces must be clean and free of dust, oil, grease, paint, tar, wax, curing agent, primer, sealer, form release agent or any deleterious substance and debris which may prevent or reduce adhesion.
- Acids, concentrated alkaline conditions and cleaning chemical residues must be neutralized or removed.
- All concrete substrates must be completely cured (at least 28 days old), solid, sound, slightly textured and have a direct tensile cohesive strength greater than 1.2 MPa (175 psi) when tested in accordance with ACI 503 R – (Appendix A) procedure.



PRO FLOWLEVEL* FIBER REINFORCED



- On grade or below grade concrete slabs must be installed over an effective vapor barrier.
- All concrete substrates must be dry and free of hydrostatic conditions and/or extreme moisture problems. Perform a calcium chloride moisture emission test (ASTM F-1869) on the concrete substrate before proceeding with the installation of the floor. For wood flooring and resilient floor covering installations, the moisture vapor emission of the concrete must not exceed 1.36 kg per 93 m² (3 lb per 1,000 sq. ft.) per 24 hours. Do not prime, repair, level or patch the substrate, or install any floor covering materials until moisture problems and conditions have been addressed to meet these requirements. Please contact our Technical Service Department for appropriate recommendations.
- Existing Gypsum and light-weight concrete surfaces must be properly primed with PRO SUPERPRIME™ or PRO SUPERPRIME™ 1C (see respective technical data sheet for details)
- Smooth concrete substrate surfaces must be either PRIMED with PRO SUPERPRIME™ or PRO SUPERPRIME™ 1C primers **OR** mechanically roughened in accordance with an engineer-approved procedure (shot-blasting, scarification, grinding, sand or waterblasting, etc) to provide sufficient surface texture and profile for the adequate bonding of the subsequent leveling product. Then, PRIMED (see respective technical data sheet
- If concrete is dry and porous, it must be primed with PRO SUPERPRIME™ or PRO SUPERPRIME™ 1C primers (see respective technical data sheet for details) to prevent an uncontrolled absorption of water out of the self-leveling mix and also to avoid formation of air bubbles on the surface (see respective technical data sheet for details).
- Existing concrete slabs with carpet adhesive or old cutback adhesive **residues** must be cleaned and properly prepared, making sure to scrape and remove any loose old cutback adhesive residue, and then **PRIMED** prior to the application of the self-leveling underlayment. (Refer to the Surface Preparation Guidelines and PRO SUPERPRIME™ or PRO SUPERPRIME™ 1C technical data sheets for full details or contact our Technical Service Department for appropriate recommendations).
- For tile installation, wood substrate must be solid and well-supported by joists spaced 400 mm (16") apart and should consist of two superimposed plywood sheet layers, each 16 mm (5/8") thick and set with a minimum of 3 mm (1/8") gap spacing between panels and 6mm (1/4") gapping along the perimeter walls, around columns, posts, drains and pipe openings. The top underlayment plywood layer must be fastened with nonoxidizing floor screws at every 15 cm (6") along panel edges and each way throughout the panel at 20 cm (8") centers. Floor surfaces along adjacent edges of panels must not be more than 0.75 mm (1/32") above or below each other. For ceramic and porcelain tiles up to 30 x 30 cm (12" x 12"), the structural design of the substrate must not allow a deflection greater than L/360 when tested to 136 kg (300 lb) concentrated loads in accordance with ASTM C627 Standard test method. For square and rectangular tiles with one edge dimension 38 cm (15") and 45 cm (18") up to 58 x 58 cm (23" x 23") the maximum deflection should not exceed L/540 unless an effective CIM (crack isolation membrane) is used in the installation system. For tiles 60 x 60 cm (24" x 24") or larger and for ALL dimension stone installation, the maximum deflection must not exceed L/720. (Refer to ANSI A108.01 requirements for Plywood sub-floors)

 Existing ceramic tile, VCT or hard to bond to surfaces should be PROPERLY PREPARED, CLEANED and PRIMED with PROMA'S PRO SUPERPRIME™ or PRO SUPERPRIME™ 1C primers prior to the application of the self-leveling underlayment. (Refer to the Surface Preparation Guidelines and PRO SUPERPRIME™ or PRO SUPERPRIME™ 1C technical data sheets for full details or contact our Technical Service Department for appropriate recommendations)

Note: Do not use sweeping compounds. This could leave an oily film on the concrete surface that will prevent a proper bond.

Mixing

Mixing ratio: 3 1/3 parts powder to 1 part water (by volume)

- Use clean mixing-tools and containers.
- 2. In a clean mixing container, measure and pour approx. 4.85 L (5.10 quarts / 1.28 US gal) of cool clean water and gradually add 18 kg (40 lb) of PRO FLOWLEVEL™ FIBER REINFORCED powder mix, while mixing slowly.
- 3. Using a low-speed mechanical mixer (150 300 rpm), mix until a homogeneous, smooth, lump-free, consistency is achieved.
- 4. The product is now ready for setting.
- 5. Use the product within the shortest possible delay (within a few minutes).

Application

Note: Protect from any direct air ventilation or heat radiation source, such as direct sunlight, during and after the installation.

- 1. Pour the self-leveling mix on the substrate and help spread it in place with a trowel or squeegee or by continuous pumping.
- 2. The mix will level itself out while leaving a smooth finish.

For more detailed information on ways to apply this product (especially when a pump process is being used), please contact our technical department for proper recommendations and job field assistance.

Note: All expansion and control joints must be carried through from substrate to final flooring and filled with an industry-approved flexible sealant in accordance with ANSI A108.01 norm and TCNA detail EJ171 or TTMAC detail 301MJ. Do not fill or cover expansion and control joints with installation material. Contact PROMA's technical department for additional information.

PRO SUPERPRIME™

PROMA has engineered a revolutionary primer that can ready nearly any surface for PROMA leveling underlayments without the need for scarifying or shotblasting. Use PRO SUPERPRIME™ or PRO SUPERPRIME™ 1C with PRO FLOWLEVEL FIBER REINFORCED as an unbeatable system for preparing a substrate for flooring installation. Surface must meet a minimum of 0.5 MPa (72 psi) tensile bond strength. In areas subject to heavy traffic, a minimum of 1.2 MPa (175 psi) tensile bond strength is required (see respective technical data sheet for details).





Cured concrete (28 days)



Metal such as

Exterior-grade plywood

Existing ceramic and quarry tiles, porcelain, granite and marble



Cement and Epoxy

Terrazzo Floors

Existing VAT, VCT, non-cushioned vinyl sheet goods, homogeneous PVC flooring

Painted, and sealed surfaces such as PRO BLOCK™ MMS ECO















Adhesive residue





Curing and Protection

- Protect from foot traffic for at least 3-4 hours and from light traffic for a period of 24 hours at normal room temperature and humidity conditions.
- Install ceramic tiles, porcelain, or natural stones, and floor covering materials, such as resilient flooring, carpet, laminate, engineered wood and wood parquet, only after PRO FLOWLEVEL™ FIBER REINFORCED has completely dried. PRO FLOWLEVEL FIBER REINFORCED dries at 1/8" (3 mm) per day on average. The below chart is provided as a general guideline for drying times:

Thickness	Drying Time
1/8" (3 mm)	24 hours
1/4" (6 mm)	48 hours
1/2" (12 mm)	96 hours
Over 1/2" (12 mm)	7-14 days*

^{*} Please contact our Technical Service department for further information.

NOTE: Porosity of the substrate, depth of application, ambient temperature, climate conditions, and ventilation can all affect drying time. **Always test the installed product to ensure it is fully dry using mat testing according to ASTM D4263, or with a moisture tester (e.g. Delmhorst Model BD-2100) when the calibrated meter reads 5% or less.**

- Do not attempt to accelerate drying and curing through forced ventilation, fans, blowers, or auxiliary heaters.
- IMPORTANT: Once dried, PRO FLOWLEVEL™ FIBER REINFORCED must be SEALED before
 any glue or mortar application. Seal surface using PRO SUPERPRIME™ or PRO PRIME™ LP
 primer at a ratio of 1 part latex to 3 parts water (1:3).
- Protect from dirt, dust, and damage from other trades until fully covered by a floor covering or tiling material.

Cleaning

Clean tools and hands with water while the product is still fresh.

Health and Safety

Refer to the Safety Data Sheet (SDS) for complete details.

6. AVAILABILITY AND COST

PROMA products are widely available in Canada and the Northeast United States. To find a distributor of PROMA products, call **toll-free:1.866.51.PROMA (77662).**

7. WARRANTY

PROMA warrants that this product is manufactured using quality raw materials and is of merchantable quality and suitable for the purpose for which it was intended. PROMA's liability under this warranty shall be limited to the replacement of its product proven to be defective. Neither seller nor manufacturer shall be liable for any injury, loss or damage, direct or consequential, arising from the use of/or the inability to use this product.

8. MAINTENANCE

Product requires no special maintenance. Do not leave without floor covering or exposed as a resurfacing material.

9. TECHNICAL SERVICE

For more detailed information on this product, please contact our technical department for proper recommendations and job field assistance. Toll-free: 1.866.51.PROMA (77662).

10. FILING SYSTEM

Additional information is available upon request, or by visiting www.proma.ca.

PROMA Adhesives Inc.

9801, Parkway, Anjou, Quebec Canada H1J 1P3

Tel.: 514.852.8585 Fax: 514.852.8225

Toll-free: 1 866.51.PROMA (77662)

Email: info@proma.ca

© 2024 PROMA Adhesives, Inc

