




BLADE CHANGE INSTRUCTIONS

For 9mm Precision Handle Knives with End/Pocket-Clip,
Including Models: A-1, ESK-1, ESP-1, SPC-1, XA-1,180, and 18mm ML


1

REMOVE POCKET CLIP
FROM BASE OF HANDLE.



2

PUSH SLIDER ASSEMBLY
PAST THE BASE OF HANDLE
TO REMOVE.




BLADE CHANGE INSTRUCTIONS


For 9mm Precision Handle Knives with End/Pocket-Clip,
Including Models: A-1, ESK-1, ESP-1, SPC-1, XA-1,180, and 18mm ML

3

CAREFULLY SLIDE USED
BLADE AND SLIDER
ASSEMBLY FROM HANDLE.
REMOVE USED BLADE FROM
ASSEMBLY AND DISPOSE OF
BLADE PROPERLY IN
SHARPS CONTAINER.

**4**

INSERT NEW BLADE INTO
HANDLE. ALIGN BY PLACING
THE HOLE IN THE BLADE
OVER THE RAISED
MOUNTING POINT ON SLIDER
ASSEMBLY.




BLADE CHANGE INSTRUCTIONS

For 9mm Precision Handle Knives with End/Pocket-Clip,
Including Models: A-1, ESK-1, ESP-1, SPC-1, XA-1,180, and 18mm ML

5

PUSH SLIDER ASSEMBLY
AND BLADE INTO HANDLE TO
LOCK INTO PLACE.

REPLACE POCKET-CLIP IN
END OF TOOL.

**6**

NEW BLADE IS NOW READY
FOR USE.

