

# **UltraCare**

# **Grout Refresh**<sup>™</sup> Universal Grout Colorant and Sealer



# DESCRIPTION

*UltraCare Grout Refresh* is a nonflammable, ready-to-use, water-based, polymermodified colorant and sealer for grout joints. It can be applied onto and bonds to cement, epoxy, urethane and acrylic grouts.

# FEATURES AND BENEFITS

- Allows grout to be changed to any UltraCare Grout Refresh color
- Restores the look of tile grout
- Seals to protect against most common stains
- Available in all 40 of MAPEI's standard grout colors
- Easy to apply and maintain
- Creates a uniform color

# **INDUSTRY STANDARDS AND APPROVALS**

#### Green certifications

• Living Building Challenge (LBC) Red List Free: This product has been verified per the most current Red List on the LBC's Website.

# WHERE TO USE

- For interior/exterior use
- For revitalizing old grout joints

• For vertical and horizontal applications

#### LIMITATIONS

• Do not clean with solvent-based cleaners once *UltraCare Grout Refresh* has been applied.

- Porous tile or natural stone may require sealing with one of MAPEI's *UltraCare* penetrating sealers, to prevent *UltraCare Grout Refresh* from absorbing into the tile. Contact MAPEI's Technical Services Department for recommendations.
- Do not use in submerged areas, such as pools or hot tubs, or in areas subject to hydrostatic pressure.
- Grout should be cured for at least 2 days before being treated with *UltraCare Grout Refresh*.
- Use only when the substrate and ambient temperatures are between 50°F and 95°F (10°C and 35°C).
- Not recommended for use over MAPEI's Kerapoxy® IEG CQ

# **SUITABLE SUBSTRATES**

- Sanded grout joints
- Unsanded grout joints
- Epoxy grout joints
- Acrylic grout joints
- Urethane grout joints

Consult MAPEI's Technical Services Department for installation recommendations regarding substrates and conditions not listed.

# SURFACE PREPARATION

 Substrate should be clean, dry and free of dust, dirt, oil, grease, paint, curing agents, concrete sealers, loosely bonded toppings, loose particles, and any other substance that may prevent or reduce adhesion.



Clean surface using MAPEI's *UltraCare* Heavy-Duty Stone, Tile & Grout Cleaner. Follow all label instructions for proper use and dilution rates.

#### MIXING

Before product use, take appropriate safety precautions. Refer to the Safety Data Sheet for details.

- 1. Shake well before using.
- 2. If two or more units of the same color are to be used, blend the liquids together to ensure color consistency.

# **PRODUCT APPLICATION**

Read all installation instructions thoroughly before installation.

- 1. Apply *UltraCare Grout Refresh* in a thin coat; if applied too thickly, the product will not bond properly. Deposit a fine bead of *UltraCare Grout Refresh* into the middle of the grout joint, avoiding the tile surface as much as possible. Spread evenly using a fine paintbrush, toothbrush or grout stain applicator, working the colorant into the grout joint using a back-and-forth motion to allow the colorant to penetrate the grout.
- 2. There are two different methods available for cleaning after applying *UltraCare Grout Refresh*. The "early wash method" should be used on smooth or polished surfaces with joints that are more flush/full. The "late wash method" should be used on textured tile surfaces that have slightly recessed grout joints.
  - 2a: Early wash method: Within 5 minutes of application, wipe the tile and grout in the same direction as the grout line with a slightly damp grout sponge to remove the excessive colorant from the tile surface. Flip the grout sponge over as needed. If colorant residue remains on tile, mist a white or blue nylon pad with water and agitate over surface. Buff dry with a paper towel or microfiber towel.
  - 2b: <u>Late wash method</u>: After the colorant has dried for 20 to 25 minutes, remove any colorant from the tile surface by lightly misting the tile with water and allowing it to stand for 5 minutes. Using a clean, damp microfiber towel, gently rub the tile surface to remove the colorant, avoiding the actual grout joint. Buff dry with a clean paper towel or microfiber towel and repeat the process, if needed, after 30 minutes. Change your wash water frequently when using *UltraCare Grout Refresh* on a larger area (more than 100 sq. ft. or 9.29 m<sup>2</sup>).
- 3. If any colorant residue remains after 12 hours, remove it using a white scrubpad in a circular motion while avoiding the joints.
- 4. *UltraCare Grout Refresh* needs 24 hours for an initial cure, depending on the type of grout onto which the colorant is applied.

- 5. If grout appearance is being changed from a dark to light color, more than 1 coat of *UltraCare Grout Refresh* may be required. Allow 1 to 2 hours between coats.
- 6. Clean tools with water after each use.

# PROTECTION

- Protect from foot traffic for 2 hours.
- Protect from water for 24 hours.
- Avoid scrubbing or excessive cleaning of grout joints for 20 days to allow a full cure.



#### Shelf Life and Application Properties

Shelf life	2 years when stored in original, unopened packaging at 73°F (23°C)
Drying time	30 to 120 minutes
VOCs (Rule #1168 of California's SCAQMD)	42 g per L
Application temperature range	50°F to 95°F (10°C to 35°C)
Colors	Available in MAPEI's palette of 40 colors organized into
	5 color collections. Refer to MAPEI's grout/caulk/colorant
	chart. Sample color chips are available upon request.

Protect containers from freezing in transit and storage.

#### Packaging

Size Bottle: 8 U.S. oz. (237 mL)

Approximate Coverage\* per 8 U.S. oz. (237 mL)

Width	Coverage
1/4" (6 mm)	50 to 300 sq. ft. (4.65 to 27.9 m <sup>2</sup> )

\* Coverage rate will vary based on application method, tile size, width of joint and porosity of grout.







Refer to the SDS for specific data related to health and safety as well as product handling.

For information on MAPEI's commitment to sustainability and transparency, as well as how MAPEI meets the health and well-being requirements of product certification programs, contact the MAPEI Sustainability Team at 1-800-992-6273.

#### LEGAL NOTICE

The contents of this Technical Data Sheet ("TDS") may be copied into another project-related document, but the resulting document shall not supplement or replace requirements per the TDS in effect at the time of the MAPEI product installation. For the most up-to-date TDS and warranty information, please visit our website at

www.mapei.com. ANY ALTERATIONS TO THE WORDING OR REQUIREMENTS CONTAINED IN OR DERIVED FROM THIS TDS SHALL VOID ALL RELATED MAPEI WARRANTIES.

Before using, the user must determine the suitability of our products for the intended use,

and the user alone assumes all risks and liability. ANY CLAIM SHALL BE DEEMED WAIVED UNLESS MADE IN WRITING TO US WITHIN FIFTEEN (15) DAYS FROM DATE IT WAS, **OR REASONABLY SHOULD HAVE BEEN, DISCOVERED**.

We proudly support the following industry organizations:









#### **MAPEI Headquarters of North America**

1144 East Newport Center Drive Deerfield Beach, Florida 33442 1-888-US-MAPEI (1-888-876-2734) / (954) 246-8888

#### **Technical Services**

1-800-992-6273 (U.S. and Puerto Rico) 1-800-361-9309 (Canada)

#### **Customer Service**

1-800-42-MAPEI (1-800-426-2734)

Services in Mexico 0-1-800-MX-MAPEI (0-1-800-696-2734)

Edition Date: May 16, 2019 PR: 5815 MK 3000084 (19-1539)

For the most current BEST-BACKED<sup>™</sup> product data and warranty information, visit www.mapei.com. All Rights Reserved. Printed in the USA. © 2019 MAPEI Corporation.