

WHERE TO USE

Repairs and structural strengthening for reinforced concrete, brickwork, stone, wooden and tuff elements damaged by physical-mechanical stress or natural causes.

Maperod C and **Maperod G** are used in combination with fabrics from the **MapeWrap** range to improve anchorage, especially when interventions are carried out to increase flexural and shear strength (for concrete, masonry and wood).

Some application examples

- Upgrading seismic performance of structures in high-risk zones.
- Setting terminal anchors and anti-delamination connectors in composite systems.
- Studding and micro-stitching.
- As a valid substitute for metal through tie-rods in masonry for reinforced structural strengthening (reinforced stitching method).
- Reducing deformation under service loads (increase in stiffness).
- Increasing load-bearing capacity (e.g. re-qualifying structures due to change in final use).
- Increasing fatigue strength.
- Increasing overall durability of the intervention.

TECHNICAL CHARACTERISTICS

Maperod C is a range of deformed, pultruded carbon fibre bars in an epoxy matrix with a peel-ply film, characterised by their high tensile strength. **Maperod C** is a valid alternative to metal bars.

The bars in the **Maperod C** range are 10 mm in diameter and have a modulus of elasticity of 155 GPa. **Maperod G** is a range of deformed, pultruded glass fibre bars in an epoxy-modified vinylester matrix, characterised by their high tensile strength. The bars in the **Maperod G** range are 10 mm in diameter and have a modulus of elasticity of 40.8 GPa.

Thanks to their composition and production process, which guarantees constant properties throughout the bars, **MapeWrap C** and **MapeWrap G** have the following characteristics:

- high tensile strength;
- lightweight;
- modulus of elasticity compatible with and suitable for the requirements of concrete and other materials used in constructions;
- easy to apply.

ADVANTAGES

Unlike interventions using traditional methods, thanks to their extremely low weight, products from the **Maperod** range may be applied extremely quickly without using special handling or lifting equipment, and often without interrupting the use of structures.



TECHNICAL DATA (typical values)		
PRODUCT IDENTITY		
	Maperod C	Maperod G
Matrix:	epoxy resin	epoxy-modified vinylester
Appearance:	solid, round structural element	
Colour:	black	white
PRODUCT CHARACTERISTICS		
	Maperod C	Maperod G
Density (g/cm³):	1.54	1.995
Fibre content (%):	71	75
Cross-section area (mm²):	73.9	71.26
Nominal diameter (mm):	9.7	9.53
FINAL PERFORMANCE		
Tensile strength (N/mm²):	2,000	760
Modulus of elasticity (N/mm²):	155,000	40,800
Elongation at failure (%):	1.5	2
Shear strength (MPa):	75	15
Coefficient of longitudinal thermal expansion (m/m/°C):	6 -10 x 10 ⁻⁶	6-10 x 10 ⁻⁶
Coefficient of transversal thermal expansion (m/m/°C):	-	21-23 x 10 ⁻⁶

Compared with the cladding technique using metal plates (béton plaqué), Maperod does not require temporary supports during application and there is no risk of corrosion of the strengthening materials applied. Compared with cladding using fabric impregnated directly on site, bars from the Maperod range may be applied very quickly and the quality of the installation is less dependent on the experience and skill of the workers.

RECOMMENDATIONS

- Before bonding, make sure the tensile strength of the substrate is sufficient.
- Do not apply Maperod on substrates which are not fully cured.
- On particularly absorbent substrates or on concrete in areas with a high level of R.H. (underpasses, underground rooms, cellars, etc.), we recommend priming the substrates with a coat of MapeWrap Primer 1 before bonding Maperod (see relative technical data sheet for preparation and application instructions). Application of MapeWrap 11 or MapeWrap 12, or as on alternative Mapefix EP must be carried out while the MapeWrap Primer 1 is still "fresh".

For applications on wooden substrates, we recommend using an epoxy adhesive from the **Mapewood** range.

APPLICATION PROCEDURE

- 1. Application phases.
- 2. Drilling the holes.
- 3. Preparation of MapeWrap Primer 1.
- 4. Application of MapeWrap Primer 1.
- 5. Preparation of MapeWrap 11 or MapeWrap 12, Mapefix EP.
- 6. Application of **MapeWrap 11** or **MapeWrap 12**, **Mapefix EP**.
- 7. Inserting the **Maperod** bars.

1. Drilling the holes

Preparation of masonry

Drill a series of holes slightly larger than the diameter of the bar in the face of the wall. The depth of the holes must be calculated by a design engineer according to the tensile requirements of the bar. Pour an epoxy binder-based product into the holes and insert the bars to the depth required until the epoxy product comes out of the holes.

Maperod C is particularly recommended as a structural strengthening system for wood. Use a product with an epoxy-based binder in such cases, as it is more compatible with wooden substrates.

Preparation of concrete

Drill a series of holes around 1.5 times the diameter of the bar in the concrete. The depth of the holes must be calculated by a design engineer according to the tensile requirements of the bar. Pour the resin into

the holes and then insert the **Maperod C/ Maperod G** bars to the bottom of the holes so that the epoxy resin is squeezed out.
Remove all traces of dust and loose material from inside the holes with compressed air.

2. Preparation of MapeWrap Primer 1

The two components which make up MapeWrap Primer 1 must be mixed together. Pour component B into component A and mix with a low-speed drill with a mixing attachment until the resin is completely blended. Mixing ratio: 3 parts by weight of component A with 1 part by weight of component B. To avoid dosage errors, use the entire contents of the two components. If only partial quantities are required, use high-precision electronic scales to weigh out the components (this procedure must also be adopted for the other products).

Once prepared, the workability time of **MapeWrap Primer 1** is approx. 90 minutes at +23°C.

3. Application of MapeWrap Primer 1

After drilling and preparing the holes, apply the **MapeWrap Primer 1** inside the holes using a bottle brush.

If the surface is particularly absorbent, apply a second coat of **MapeWrap Primer 1** once the first coat has been completely absorbed. Then apply **MapeWrap 11**, **MapeWrap 12** or **Mapefix EP** while the product underneath is still "fresh".

4. Preparation of MapeWrap 11, MapeWrap 12 and Mapefix EP MapeWrap 11 or MapeWrap 12

MapeWrap 11 or MapeWrap 12 must be chosen according to the surrounding temperature and workability time (MapeWrap 12 has a higher workability time than MapeWrap 11).

Pour component B into component A and mix with a low-speed drill with a mixing attachment until they form an even, grey paste.

Mixing ratio for both products: 3 parts by weight of component A with 1 part by weight of component B. At +23°C, **MapeWrap 11** remains workable for around 40 minutes after mixing, while **MapeWrap 12** remains workable for around 60 minutes.

Mapefix EP

Mapefix EP is a two-component product supplied in bi-axial 385 ml cartridges and comprises two separate components, A (resin) and B (catalyser). They are mixed together during extrusion from the cartridge through a static mixer supplied with the product. This product may be applied at +5°C to +40°C.

5. Application of MapeWrap 11 or MapeWrap 12 and Mapefix EP

Completely fill the holes previously treated with MapeWrap Primer 1 while it is still "fresh". Apply MapeWrap 11 or MapeWrap 12 in the holes using an empty sealant cartridge filled with product and an extrusion gun, and Mapefix EP through the static mixer supplied with the product using an extrusion gun.

6. Inserting the Maperod bars

Maperod C and Maperod G are supplied in lengths of 2 meters and 6 metres respectively, and are cut to length on site using a diamond cutting disk. Insert the Maperod bars while applying a constant pressure along their entire length. Remove excess resin with a trowel, taking care not to move the bars.

When applied on curved elements, the bars must be held in position with clamps or stays until the resin has completely hardened (24 hours is usually enough before the clamps or stays can be removed).

PRECAUTIONS TO BE TAKEN DURING AND AFTER APPLICATION

- The temperature during application must be at least +5°C and the structure must be protected from rain and dust carried by the wind.
- After completing application, make sure the treated surface is kept at a temperature of at least +5°C until the products are completely cured.
- Protect the surface from rain for at least 24 hours if the temperature does not drop below +15°C, or for at least 3 days if the temperature is lower.

Cleaning

MapeWrap 11 and MapeWrap 12 form a strong bond, including on metal. Cleaning tools with solvent (such as ethanol, toluene, etc.) before they harden is recommended.

PACKAGING

Maperod C and **Maperod G** are supplied in boxes of 10x2 metre lengths and 10x6 metre lengths respectively.

Maperod C and **Maperod G** are supplied in 10 mm diameter lengths.

STORAGE

Store in a covered, dry area.

PRECAUTIONS TO BE TAKEN WHEN HANDLING THE PRODUCTS

All workers must wear waterproof rubber gloves, goggles and protective clothing when preparing and applying the bars and epoxy systems (MapeWrap 11, MapeWrap 12 and Mapefix EP). Avoid contact with the eyes or skin. If they come into contact with the skin, wash off with plenty of soap and water. If they come into contact with the eyes, wash with plenty of clean water and seek medical attention.

If the products are applied in closed environments, make sure they are well ventilated to guarantee a continuous circulation of fresh air.

For further and complete information about the safe use of our product please refer to our latest version of the Material Safety Data Sheet.

PRODUCT FOR PROFESSIONAL USE.

WARNING

Although the technical details and recommendations contained in this product



data sheet correspond to the best of our knowledge and experience, all the above information must, in every case, be taken as merely indicative and subject to confirmation after long-term practical application: for this reason, anyone who intends to use the product must ensure beforehand that it is suitable for the envisaged application: in every case, the user alone is fully responsible for any consequences deriving from the use of the product.

Please refer to the current version of the Technical Data Sheet, available from our website www.mapei.com

All relevant references for the product are available upon request and from www.mapei.com

